












قطعات کنسول نینتندو سویچ لایت

شماره	عکس	مشخصات قطعه
DIEHARD - NSliteparts- 001	 <p>For Switch Lite</p> <p>D I E H A R D</p>	Dust Prevent Net Mesh Replacement Cooler Filter Left Right Speaker Dust-Net for Switch Lite Console
DIEHARD - NSliteparts- 002	 <p>For Switch Lite Speaker</p> <p>D I E H A R D</p>	Dust Prevent Net Mesh Replacement Cooler Filter Left Right Speaker Dust-Net for Switch Lite Speaker
DIEHARD - NSliteparts- 003	 <p>D I E H A R D</p>	GPU Heat Sink Replacement Parts for NS Switch Lite (Pulled)
DIEHARD - NSliteparts- 004	 <p>D I E H A R D</p>	Original Ear Phone Jack Connector Replacement for Switch Lite
DIEHARD - NSliteparts- 005	 <p>D I E H A R D</p>	Original Ear Phone Jack Connector Module Replacement for Switch Lite

<p>DIEHARD - NSliteparts- 006</p>	 <p style="text-align: center;">D I E H A R D</p>	<p>OEM New USB Type-C Charging Port Connector Replacement Parts for NS switch Lite</p>
<p>DIEHARD - NSliteparts- 007</p>	 <p style="text-align: center;">D I E H A R D</p>	<p>Original Pulled USB Type-C Charging Port Connector Replacement Parts for NS switch Lite</p>
<p>DIEHARD - NSliteparts- 008</p>	 <p style="text-align: center;">D I E H A R D</p>	<p>Replacement Buttons Conductive for NS switch Lite console</p>
<p>DIEHARD - NSliteparts- 009</p>	 <p style="text-align: center;">D I E H A R D</p>	<p>Replacement Buttons Conductive ABXY Rubber 4-Piece Set for NS switch Lite Right</p>
<p>DIEHARD - NSliteparts- 010</p>	 <p style="text-align: center;">D I E H A R D</p>	<p>Replacement Buttons Conductive D-Pad Rubber 4-Piece Set for NS switch Lite Left</p>
<p>DIEHARD - NSliteparts- 011</p>	 <p style="text-align: center;">D I E H A R D</p>	<p>Original Inner Cooling Fan Spare Parts for NS Switch Lite</p>

<p>DIEHARD - NSliteparts- 012</p>	 <p style="text-align: center;">D I E H A R D</p>	<p>Original Game Card Reader Slot Socket Spare Parts for NS Switch Lite</p>
<p>DIEHARD - NSliteparts- 013</p>	 <p style="text-align: center;">D I E H A R D</p>	<p>Original Game Card Reader Slot Socket with earphone port sicket Spare Parts for NS Switch Lite</p>
<p>DIEHARD - NSliteparts- 014</p>	 <p style="text-align: center;">D I E H A R D</p>	<p>New!TF SD Reader connector Repair Parts for NS switch lite</p>
<p>DIEHARD - NSliteparts- 015</p>	 <p style="text-align: center;">D I E H A R D</p>	<p>3set,2pcs/set,Silicon cap For Switch Lite Joy con</p>
<p>DIEHARD - NSliteparts- 016</p>	 <p style="text-align: center;">D I E H A R D</p>	<p>Original Outer Glass Touch Screen Digitizer Replacement Parts for Switch lite</p> <p>Color: Black,Pink,Blue,Gray, Yellow</p>
<p>DIEHARD - NSliteparts- 017</p>	 <p style="text-align: center;">D I E H A R D</p>	<p>SKU: WRNSL004Original LCD Screen Display Replacement Repair Parts for NS switch lite</p>

<p>DIEHARD - NSliteparts- 018</p>	 <p style="text-align: center;">D I E H A R D</p>	<p>Original For NS LITE Game Console L Button Board Keyboard For NS Switch Lite Left Funtion Circuit Board</p>
<p>DIEHARD - NSliteparts- 019</p>	 <p style="text-align: center;">D I E H A R D</p>	<p>Left Ribbon Cable repalcement for Switch Lite Button Board</p>
<p>DIEHARD - NSliteparts- 020</p>	 <p style="text-align: center;">D I E H A R D</p>	<p>Power Sound Volume Ribbon Flex Cable for NS Switch lite Replacement Part</p>
<p>DIEHARD - NSliteparts- 021</p>	 <p style="text-align: center;">D I E H A R D</p>	<p>Replacement Original ZR Key Plastic Button for Switch lite Left white</p>
<p>DIEHARD - NSliteparts- 022</p>	 <p style="text-align: center;">D I E H A R D</p>	<p>Replacement Original ZL Key Plastic Button for Switch lite Left white</p>

<p>DIEHARD - NSliteparts- 023</p>	 <p style="text-align: center;">D I E H A R D</p>	<p>Replacement Original R Key Plastic Button for Switch lite Left white</p>
<p>DIEHARD - NSliteparts- 024</p>	 <p style="text-align: center;">D I E H A R D</p>	<p>Replacement Original L Key Plastic Button for Switch lite Left white</p>
<p>DIEHARD - NSliteparts- 025</p>	 <p style="text-align: center;">D I E H A R D</p>	<p>original MAX77812 BGA chip for NS Nintendo Switch Lite Console Power IC Chip Motherboard Component</p>
<p>DIEHARD - NSliteparts- 026</p>	 <p style="text-align: center;">D I E H A R D</p>	<p>Replacemen For Switch Lite Controller MAX77620H chips Power IC BGA</p>
<p>DIEHARD - NSliteparts- 027</p>	 <p style="text-align: center;">D I E H A R D</p>	<p>Original Switch Lite game card slot IC chip BGA for For Nintend Switch lite repair parts accessories</p>
<p>DIEHARD - NSliteparts- 028</p>	 <p style="text-align: center;">D I E H A R D</p>	<p>CYW4356X KUNG CYW4356 KUNG chip IC replaced with Nintendo Switch Lite CYW4356XKUBG game console wifi BGA IC chip</p>

<p>DIEHARD - NSliteparts- 029</p>	 <p style="text-align: center;">D I E H A R D</p>	<p>For Nintendo Switch Lite console Motherboard Touch Screen Digitizer fpc connector plug socket slot</p>
<p>DIEHARD - NSliteparts- 030</p>	 <p style="text-align: center;">D I E H A R D</p>	<p>For Nintendo Switch Lite console Motherboard LCD screen display Digitizer fpc connector plug socket slot</p>
<p>DIEHARD - NSliteparts- 031</p>	 <p style="text-align: center;">D I E H A R D</p>	<p>Original New For Nintendo Switch lite Console 29pin L button Ribbon Power Circuit flex cable motherboard plug socket</p>
<p>DIEHARD - NSliteparts- 032</p>	 <p style="text-align: center;">D I E H A R D</p>	<p>LR ZL ZR Full Set Buttons Joystick Trigger For Switch Lite Game Controller Replacement Parts 11pieces/set</p>
<p>DIEHARD - NSliteparts- 033</p>	 <p style="text-align: center;">D I E H A R D</p>	<p>Original Replacement R L ZR ZL Key Plastic Button for Switch Lite 4pieces/Set</p> <p style="text-align: center;">Black</p>
<p>شماره</p>	<p>عكس</p>	<p>مشخصات قطعه</p>
<p>قطعات کنسول نینتندو سویچ لایت</p>		



POWERED BY TAJAN -CO 2021-2022