























قطعات کنسول نینتندو سویچ NS Console

شماره	عکس	مشخصات قطعه
DIEHARD - NsParts-001	 <p>D I E H A R D</p>	Original LCD Screen Display Repair Parts for NS Switch
DIEHARD - NsParts-002	 <p>D I E H A R D</p>	Original Outer Glass Touch Screen Digitizer Replacement Parts for Nintendo Switch Old version - Black
DIEHARD - NsParts-003	 <p>D I E H A R D</p>	Original Outer Glass Touch Screen Digitizer Replacement Parts for Nintendo Switch New version - Black
DIEHARD - NsParts-004	 <p>D I E H A R D</p>	17Pieces in XBOX ONE PS4 SWITCH T8 T10 1.5Y game pad screw driver opening tool kit

<p>DIEHARD - NsParts-005</p>	 <p style="text-align: center;">D I E H A R D</p>	<p>7Pieces in XBOX ONE PS4 SWITCH T6 T8H T10H game pad screw driver opening tool kit</p>
<p>DIEHARD - NsParts-006</p>	 <p style="text-align: center;">D I E H A R D</p>	<p>Screw driver kit for NS switch</p>
<p>DIEHARD - NsParts-007</p>	 <p style="text-align: center;">D I E H A R D</p>	<p>OEM Left Right SL SR Button with LED Flex Cable Set replacement for nintendo Switch Joy-con</p>
<p>DIEHARD - NsParts-008</p>	 <p style="text-align: center;">D I E H A R D</p>	<p>OEM L ZL ZR Left Right Trigger and Minus switch Button Flex Cable for Nintendo Switch joycon</p>
<p>DIEHARD - NsParts-009</p>	 <p style="text-align: center;">D I E H A R D</p>	<p>ORIGINAL new L ZL ZR Left Right Trigger and Minus switch Button Flex Cable for Nintendo Switch joycon</p>
<p>DIEHARD - NsParts-010</p>	 <p style="text-align: center;">D I E H A R D</p>	<p>Power Sound Volume Ribbon Flex Cable for NS Switch Replacement Part</p>

<p>DIEHARD - NsParts-011</p>	 <p style="text-align: center;">D I E H A R D</p>	<p>Left and Right Plastic Rail Assembly with Flex Cable Replacement for Switch Joy-con</p>
<p>DIEHARD - NsParts-012</p>	 <p style="text-align: center;">D I E H A R D</p>	<p>Dust Prevent Net Mesh Replacement Cooler Filter Left Right Speaker Dust-Net for Switch Console □</p>
<p>DIEHARD - NsParts-013</p>	 <p style="text-align: center;">D I E H A R D</p>	<p>Original Left Right SL SR Button with LED Flex Cable Set replacement for nintendo Switch Joy-con</p>
<p>DIEHARD - NsParts-014</p>	 <p style="text-align: center;">D I E H A R D</p>	<p>Type-C Connector socket for NS switch console</p>
<p>DIEHARD - NsParts-015</p>	 <p style="text-align: center;">D I E H A R D</p>	<p>Original RL ZL ZR Ribbon Flex Cable for Switch Pro Controller</p>
<p>DIEHARD - NsParts-016</p>	 <p style="text-align: center;">D I E H A R D</p>	<p>Left and Right Joy-Con Part HD Rumble with Flex replacement for Nintendo switch Pulled</p>

<p>DIEHARD - NsParts-017</p>	 <p style="text-align: center;">D I E H A R D</p>	<p>Motor Part HD Rumble replacement for Nintendo Switch Pro Controller</p>
<p>DIEHARD - NsParts-018</p>	 <p style="text-align: center;">D I E H A R D</p>	<p>GPU Heat Sink Replacement Parts for NS Switch (Pulled)</p>
<p>DIEHARD - NsParts-019</p>	 <p style="text-align: center;">D I E H A R D</p>	<p>Right hand Controller NFC Antenna Sensor Module replacement for NS Switch Right JoyCon</p>
<p>DIEHARD - NsParts-020</p>	 <p style="text-align: center;">D I E H A R D</p>	<p>Replacement Original 3D Analog Joystick Controller for NS Switch Pro and Wii U Gamepad</p>
<p>DIEHARD - NsParts-021</p>	 <p style="text-align: center;">D I E H A R D</p>	<p>Replacement Original 3D Analog Joystick Controller for NS switch Pro and Wii U Gamepad - Green</p>
<p>DIEHARD - NsParts-022</p>	 <p style="text-align: center;">D I E H A R D</p>	<p>Original joystick mushroom for Switch Pro controller Black</p>

<p>DIEHARD - NsParts-023</p>	 <p style="text-align: center;">D I E H A R D</p>	<p>OEM joystick mushroom for Switch Pro controller Black</p>
<p>DIEHARD - NsParts-024</p>	<p style="text-align: center; color: magenta;">Original W/ Screws</p>  <p style="text-align: center;">D I E H A R D</p>	<p>Original Rear Plastic Kick Stand with screw Replacement for NS Switch</p>
<p>DIEHARD - NsParts-025</p>	 <p style="text-align: center;">D I E H A R D</p>	<p>OEM Rear Plastic Kick Stand Replacement with screw for NS Switch</p>
<p>DIEHARD - NsParts-026</p>	 <p style="text-align: center;">D I E H A R D</p>	<p>Screen Black Adhesive Strips Sticker for NS Switch</p>
<p>DIEHARD - NsParts-027</p>	 <p style="text-align: center;">D I E H A R D</p>	<p>Original WIFI Antenna Board WLAN antenna Set for NS Switch</p>
<p>DIEHARD - NsParts-028</p>	 <p style="text-align: center;">D I E H A R D</p>	<p>Original Charging Base LED Display Lamp for Nintend Switch Switch NS Game Power Indicator Lamp Flex Cable</p>







<p>DIEHARD - NsParts-029</p>	 <p style="text-align: center;">D I E H A R D</p>	<p>Circuit Board PCB Direction/ABXY Button Pad Set for NS Switch Joy-con Repair</p>
<p>DIEHARD - NsParts-030</p>	 <p style="text-align: center;">D I E H A R D</p>	<p>Original HDMI Type-c Port Connecting Flex Cable for NS Switch Dock</p>
<p>DIEHARD - NsParts-031</p>	 <p style="text-align: center;">D I E H A R D</p>	<p>Original Ear Phone Jack Connector Replacement for Switch</p>
<p>DIEHARD - NsParts-032</p>	 <p style="text-align: center;">D I E H A R D</p>	<p>Original Release Button replacement for Switch Joy-con Controller 2pieces/Set</p>
<p>DIEHARD - NsParts-033</p>	 <p style="text-align: center;">D I E H A R D</p>	<p>Complete Key Button Accessories for Nintendo switch L R Joycon Controller</p> <p>Color : Black, Gray,Red,Blue,Red □</p>






<p>DIEHARD - NsParts-034</p>	 <p>D I E H A R D</p>	<p>For Nintendo Switch NS Pro Controller Removable Round Dpad Direction Key Flat D Pad Cross Button</p>
<p>DIEHARD - NsParts-035</p>	 <p>D I E H A R D</p>	<p>Charging IC Chips bq24193 fix Parts Replacement for Nintendo Switch</p>
<p>DIEHARD - NsParts-036</p>	 <p>M92T36 QFN40</p> <p>D I E H A R D</p>	<p>Original Power Charging Control IC Chip M92T36 Replacement for Nintendo Switch Motherboard Repair</p>
<p>DIEHARD - NsParts-037</p>	 <p>M92T17</p> <p>D I E H A R D</p>	<p>Replacement For NS Switch HDMI IC Chip M92T17 motherboard ic M92T17 original</p>
<p>DIEHARD - NsParts-038</p>	 <p>M92T18 541379</p> <p>chao</p> <p>D I E H A R D</p>	<p>M92T18 QFN-40 for NS switch console mother board power ic chip</p>

<p>DIEHARD - NsParts-039</p>	 <p>D I E H A R D</p>	<p>Charging Control IC M92T55 Chips Fix Parts Replacement for Nintendo Swtich Dock</p>
<p>DIEHARD - NsParts-040</p>	 <p>D I E H A R D</p>	<p>Battery Foot Detection IC Board for NS SWITCH MAX17050X 17050 BGA</p>
<p>DIEHARD - NsParts-041</p>	 <p>D I E H A R D</p>	<p>Original new ns switch sound card chip ic ALC5639-CGT ALC5639 QFN48</p>
<p>DIEHARD - NsParts-042</p>	<p>MAX77620AEWJ+T</p>  <p>D I E H A R D</p>	<p>Power Control IC MAX77620AEWJ+T PMIC Chips Fix Parts Replacement for Nintendo Swtich</p>
<p>DIEHARD - NsParts-043</p>	 <p>D I E H A R D</p>	<p>MAX77621AEWI MAX77621 Voltage Regulator Buck Power BGA IC Chip for Nintendo Switch Console Motherboard Repair Part Accessories</p>
<p>DIEHARD - NsParts-044</p>	 <p>D I E H A R D</p>	<p>original control ic chip for switch game solt card</p>







<p>DIEHARD - NsParts-045</p>	 <p>D I E H A R D</p>	<p>EMMC 32G Storage Memory Module replacement for Nintendo Switch Console</p>
<p>DIEHARD - NsParts-046</p>	 <p>BCM4356XKUBG</p> <p>D I E H A R D</p>	<p>Original Wifi Control BCM4356XKUBG BGA IC Chip for NS Switch</p>
<p>DIEHARD - NsParts-047</p>	 <p>Lock Spring</p> <p>D I E H A R D</p>	<p>Clip Buckle Lock Springs Part for NS Switch Joy-con L R</p>
<p>DIEHARD - NsParts-048</p>	 <p>L/R/ZL/ZR</p> <p>D I E H A R D</p>	<p>Repair Spring For Nintendo Switch Controller L R ZL ZR Nintendo Switch NS Joy-con Joycon</p>
<p>DIEHARD - NsParts-049</p>	 <p>D I E H A R D</p>	<p>New USB Type-C Charging Port Connector Replacement Parts for NS switch</p>
<p>DIEHARD - NsParts-050</p>	 <p>Charger Socket</p> <p>D I E H A R D</p>	<p>Charging Port Power Connector TV Type-C Charger Socket For Nintendo Switch NS Console Charging Port Socket Original</p>

<p>DIEHARD - NsParts-051</p>	 <p style="text-align: center;">D I E H A R D</p>	<p>Replacement Buttons Conductive Rubber for NS Switch</p>
<p>DIEHARD - NsParts-052</p>	 <p style="text-align: center;">D I E H A R D</p>	<p>Replacement Buttons Conductive D-Pad Rubber 5-Piece Set for NS Switch Right Joy-con</p>
<p>DIEHARD - NsParts-053</p>	 <p style="text-align: center;">D I E H A R D</p>	<p>Replacement Buttons Conductive D-Pad Rubber 5-Piece Set for NS Switch Left Joy-con</p>
<p>DIEHARD - NsParts-054</p>	 <p style="text-align: center;">D I E H A R D</p>	<p>Original L R Locking and Quick Release Clip Set for NS Switch joy-con</p>
<p>DIEHARD - NsParts-055</p>	 <p style="text-align: center;">D I E H A R D</p>	<p>Metal L R Left & Right Plastic Clips Buckle Lock Catch Set for NS Switch joy-con</p>
<p>DIEHARD - NsParts-056</p>	 <p style="text-align: center;">D I E H A R D</p>	<p>Original Inner Speaker Replacement for NS Switch</p>






<p>DIEHARD - NsParts-057</p>	 <p style="text-align: center;">D I E H A R D</p>	<p>Original PCBA Motherboard Circuit Module Board for NS Switch Joy-con Right</p>
<p>DIEHARD - NsParts-058</p>	 <p style="text-align: center;">D I E H A R D</p>	<p>Original PCBA Motherboard Circuit Module Board for NS Switch Joy-con Left</p>
<p>DIEHARD - NsParts-059</p>	 <p style="text-align: center;">D I E H A R D</p>	<p>Middle Frame Housing Cover Replacement for Nintendo Switch Console (Pulled)</p>
<p>DIEHARD - NsParts-060</p>	 <p style="text-align: center;">D I E H A R D</p>	<p>Original Dock Motherboard PCBA Board for Nintendo Switch</p>
<p>DIEHARD - NsParts-061</p>	 <p style="text-align: center;">D I E H A R D</p>	<p>Original 3.7V 4310mAh Rechargeable Li-ion Battery HAC-003 for NS Switch console</p>
<p>DIEHARD - NsParts-062</p>	 <p style="text-align: center;">D I E H A R D</p>	<p>Original Inner Cooling Fan Spare Parts for NS Switch</p>

<p>DIEHARD - NsParts-063</p>	 <p style="text-align: center;">D I E H A R D</p>	<p>Original SD Reader Conector Board Repair Parts HAC-SD-01 for NS Switch</p>
<p>DIEHARD - NsParts-064</p>	 <p style="text-align: center;">D I E H A R D</p>	<p>OEM TF SD Reader Conector Board Repair Parts HAC-SD-01 for NS Switch</p>
<p>DIEHARD - NsParts-065</p>	 <p style="text-align: center;">D I E H A R D</p>	<p>Original Game Card Reader Slot Socket Spare Parts for NS Switch</p>
<p>DIEHARD - NsParts-066</p>	 <p style="text-align: center;">D I E H A R D</p>	<p>Original Game Card Slot Reader and 3.5MM Audio Jack Part for NS Switch New Version 2nd Gen</p>
<p>DIEHARD - NsParts-067</p>	 <p style="text-align: center;">D I E H A R D</p>	<p>Original Game Card Slot Reader and 3.5MM Audio Jack Part Replacement for NS Switch (Old Version NFT-K12D)</p>
<p>DIEHARD - NsParts-068</p>	 <p style="text-align: center;">D I E H A R D</p>	<p>Universal Game Card Slot Reader and 3.5MM Jack part replacement for NS Switch (Old version and New Version)</p>







<p>DIEHARD - NsParts-069</p>	 <p style="text-align: center;">D I E H A R D</p>	<p>Original Used HDMI-compatible Port Socket Connector Motherboard for Nintendo Switch Output Charging Dock Port Socket PCB Board</p>
<p>DIEHARD - NsParts-070</p>	<p style="text-align: center; color: magenta;">P13USB30532ZLEX</p>  <p style="text-align: center;">D I E H A R D</p>	<p>Original P13USB Pericom Audio Video Control IC Chips for NS Switch</p>
<p>DIEHARD - NsParts-071</p>	 <p style="text-align: center;">D I E H A R D</p>	<p>Analog Top Cover Thumbstick Cap for NS Switch Pro Wireless Controller Black 1PC</p>
<p>DIEHARD - NsParts-072</p>	 <p style="text-align: center;">D I E H A R D</p>	<p>Mini Portable Replacement Dock Case Cover with Screws for NS Switch</p>
<p>DIEHARD - NsParts-073</p>	 <p style="text-align: center;">D I E H A R D</p>	<p>Full Screws Set Replacement for Nintendo Switch Console 17PIECES</p>
<p>DIEHARD - NsParts-074</p>	 <p style="text-align: center;">D I E H A R D</p>	<p>Original NEW 3D Button Analog Sticks Controller Thumbstick Replacement Parts for NS switch and Switch Lite</p>

<p>DIEHARD - NsParts-075</p>	 <p style="text-align: center;">D I E H A R D</p>	<p>original Replacement Game cartridge card reader slot module 38 pin FPC connector socket for Nintendo Switch motherboard</p>
<p>DIEHARD - NsParts-076</p>	 <p style="text-align: center;">D I E H A R D</p>	<p>Original LCD Screen Flex Cable Clip Ribbon Connector Socket Fits For Switch NS Console Repair Parts Replacement</p>
<p>DIEHARD - NsParts-077</p>	 <p style="text-align: center;">D I E H A R D</p>	<p>Original Touch Screen Connector Socket Replacement Part for NS Switch Motherboard Repair</p>
<p>DIEHARD - NsParts-078</p>	 <p style="text-align: center;">D I E H A R D</p>	<p>Original Memory Card Module Connector Socket Parts for Switch Motherboard Repair</p>
<p>DIEHARD - NsParts-079</p>	 <p style="text-align: center;">D I E H A R D</p>	<p>Original SL SR Flex Connector Socket Parts Replacement for Switch Joycon</p>
<p>DIEHARD - NsParts-080</p>	 <p style="text-align: center;">D I E H A R D</p>	<p>Original rail slider connector socket parts for Switch joycon</p>

<p>DIEHARD - NsParts-081</p>	 <p>D I E H A R D</p>	<p>Original NFC and ZL Flex Connector Socket Parts Replacement for Switch Joycon</p>
<p>DIEHARD - NsParts-082</p>	 <p>D I E H A R D</p>	<p>Original 4pin ZL and ZR Flex Socket Connector Port for Switch Joycon</p>
<p>DIEHARD - NsParts-083</p>	 <p>D I E H A R D</p>	<p>Original Internal Battery Connector Parts for Nintendo Switch Console</p>
<p>DIEHARD - NsParts-084</p>	 <p>D I E H A R D</p>	<p>11Pin Left Right Slider Flex Cable Connector Port Spare Parts for Switch Joycon and Console</p>
<p>DIEHARD - NsParts-085</p>	 <p>D I E H A R D</p>	<p>Original Joy-Con IR Camera Module Camera Assembly For Nintend NS Switch Right Joycon</p>
<p>DIEHARD - NsParts-086</p>	 <p>D I E H A R D</p>	<p>Key Button Mode Accessoires for Switch L R Joycon Controller - Colors</p>

<p>DIEHARD - NsParts-087</p>	 <p style="text-align: center;">D I E H A R D</p>	<p>Thumb Grips Analog Caps Silicone Rubber For NS switch Joy-con 1PC</p>
<p>DIEHARD - NsParts-088</p>	 <p style="text-align: center;">D I E H A R D</p>	<p>New Cut Cat Paw Thumb Grips Analog Caps Silicone Rubber For NS switch Joy-con (In bulk)</p>
<p>DIEHARD - NsParts-089</p>	<p style="text-align: center;">Universal for Switch + Switch Lite</p>  <p style="text-align: center;">D I E H A R D</p>	<p>Silicone Plastic Caps Extender Thumb Stick Grip Joystick Cap Thumb Cover for Nintend Switch Joy-Con NS Switch Lite Controller</p>
<p>DIEHARD - NsParts-090</p>	 <p style="text-align: center;">D I E H A R D</p>	<p>Anti-slip Silicone Thumb Stick Grips Caps for NS Switch - 5 Colors</p>
<p>DIEHARD - NsParts-091</p>	 <p style="text-align: center;">D I E H A R D</p>	<p>Thumb stick grip caps 1PC</p>
<p>DIEHARD - NsParts-092</p>	<p style="text-align: center;">款式编号如下图所示</p>  <p style="text-align: center;">D I E H A R D</p>	<p>New Thumb Grips Analog Caps Silicone Rubber For NS Switch Joy-con 1PC</p>

<p>DIEHARD - NsParts-093</p>	 <p>D I E H A R D</p>	<p>Thumb Grips Analog Caps Silicone Rubber For NS Switch Joy-con 1PC</p>
<p>DIEHARD - NsParts-094</p>	 <p>D I E H A R D</p>	<p>thumbsticks grips caps for NS switch joy-con 1Piece</p>
<p>DIEHARD - NsParts-095</p>	 <p>D I E H A R D</p>	<p>Crossing Animal thumbsticks grips caps for NS switch joy-con 1Piece rude Package available if needed</p>
<p>DIEHARD - NsParts-096</p>	 <p>D I E H A R D</p>	<p>Thumb Grips Analog Caps Silicone Rubber For NS switch Joy-con 1PC</p>
<p>DIEHARD - NsParts-097</p>	 <p>D I E H A R D</p>	<p>3set,2pcs/set,Silicon cap For Switch Lite Joy con</p>
<p>DIEHARD - NsParts-098</p>	 <p>D I E H A R D</p>	<p>Protective Carry Case for Switch Pokemon Ball Plus</p>







<p>DIEHARD - NsParts-099</p>	 <p style="text-align: center;">D I E H A R D</p>	<p>Silicon case for Switch Pokemon Ball Plus Thumb stick cap 1PC</p>
<p>DIEHARD - NsParts-100</p>	 <p style="text-align: center;">D I E H A R D</p>	<p>Silicon case for Switch Pokemon Ball Plus Thumb stick cap 1 color 6pcs/set Total:5 colors</p>
<p>DIEHARD - NsParts-101</p>	 <p style="text-align: center;">D I E H A R D</p>	<p>Replacement Complete Housing Shell Case for Nintendo Switch Console - Black</p>
<p>DIEHARD - NsParts-102</p>	 <p style="text-align: center;">D I E H A R D</p>	<p>Replacement Screwdriver Rubber for Switch Inner Cooling Fan</p>
<p>DIEHARD - NsParts-103</p>	 <p style="text-align: center;">D I E H A R D</p>	<p>Original Inner Metal Shield Plate for Switch</p>
<p>DIEHARD - NsParts-104</p>	 <p style="text-align: center;">D I E H A R D</p>	<p>Shoulder L R ZL ZR Key Buttons Set for NS switch Joycon Controller Colors: Yellow,Green,Blue,Red</p>


<p>DIEHARD - NsParts-105</p>	 <p style="text-align: center;">D I E H A R D</p>	<p>Replacmenet SL SR Plastic Button Set for Switch Joycon</p> <p>2Pieces/Set</p>
<p>DIEHARD - NsParts-106</p>	 <p style="text-align: center;">D I E H A R D</p>	<p>Replacement Rear Back Cover for NS switch Console Replacement Rear Back Cover for NS switch Console</p>
<p>DIEHARD - NsParts-107</p>	 <p style="text-align: center;">D I E H A R D</p>	<p>Replacement Rear Back Limited Cover for NS switch new 2gen</p>
<p>DIEHARD - NsParts-108</p>	 <p style="text-align: center;">D I E H A R D</p>	<p>Replacement Rear Back Animal Crossing Limited Cover for NS switch</p>
<p>DIEHARD - NsParts-109</p>	 <p style="text-align: center;">D I E H A R D</p>	<p>Replacement Housing Cover Case DIY Set for Nintendo Switch Conosle and Joy-con Clear</p>
<p>DIEHARD - NsParts-110</p>	 <p style="text-align: center;">D I E H A R D</p>	<p>Replacement Housing Cover Case DIY Set for Nintendo Switch Conosle and Joy-con Clear Blue</p>

<p>DIEHARD - NsParts-111</p>	 <p style="text-align: center;">D I E H A R D</p>	<p>Replacement Housing Cover Case DIY Set for Nintendo Switch Conosle and Joy-con Clear Red</p>
<p>DIEHARD - NsParts-112</p>	 <p style="text-align: center;">D I E H A R D</p>	<p>Replacement Rear Back Housing Cover Case for Nintendo switch Conosle White</p>
<p>DIEHARD - NsParts-113</p>	 <p style="text-align: center;">D I E H A R D</p>	<p>Replacement Rear Front+Back Pure Black Cover for NS switch</p>
<p>DIEHARD - NsParts-114</p>	 <p style="text-align: center;">D I E H A R D</p>	<p>Replacement Rear Back Dragon Ques Limited Cover for NS switch</p>
<p>DIEHARD - NsParts-115</p>	 <p style="text-align: center;">D I E H A R D</p>	<p>Replacement Rear Back DISNEY Limited Cover for NS switch</p>
<p>DIEHARD - NsParts-116</p>	 <p style="text-align: center;">D I E H A R D</p>	<p>Replacement Rear Back PicachuLimited Cover for NS switch</p>


<p>DIEHARD - NsParts-117</p>	 <p>D I E H A R D</p>	<p>Replacement Rear Back Pokemon Limited Cover for NS Switch</p>
<p>DIEHARD - NsParts-118</p>	 <p>D I E H A R D</p>	<p>Replacement Rear Back Housing Cover Case for Nintendo Switch Console Black</p>
<p>DIEHARD - NsParts-119</p>	 <p>D I E H A R D</p>	<p>OEM high quality Inner Rechargeable Battery HAC-006 525mAh 3.7V for Nintendo switch joy-con Controller 1:1</p>
<p>DIEHARD - NsParts-120</p>	 <p>D I E H A R D</p>	<p>Original Inner Rechargeable Battery HAC-006 525mAh 3.7V for Nintendo Switch Joy-con Controller</p>
<p>DIEHARD - NsParts-121</p>	 <p>D I E H A R D</p>	<p>Left and Right Housing Cover Case Set for Switch Joy-con Multi colors</p>

<p>DIEHARD - NsParts-122</p>	 <p style="text-align: center;">D I E H A R D</p>	<p>More designs available</p>
<p>DIEHARD - NsParts-123</p>	<p style="text-align: center;">For SWITCH</p>  <p style="text-align: center;">D I E H A R D</p>	
<p>DIEHARD - NsParts-124</p>	 <p style="text-align: center;">D I E H A R D</p>	<p>Left and Right Housing Cover Case Set replacment for Switch Joy-con Transparent pink</p>
<p>DIEHARD - NsParts-125</p>	 <p style="text-align: center;">D I E H A R D</p>	<p>Lcover Case Set replacment for switch Joy- con khaki</p>
<p>DIEHARD - NsParts-126</p>	 <p style="text-align: center;">D I E H A R D</p>	<p>Left and Right Housing Cover Case Set replacment for Switch Joy-con Transparent yellow</p>
<p>DIEHARD - NsParts-127</p>	 <p style="text-align: center;">D I E H A R D</p>	<p>Left and Right Housing Cover Case Set for Switch Joy-con Clear Transparet Color:Clear Black,Clear White,</p>

<p>DIEHARD - NsParts-128</p>	 <p style="text-align: center;">D I E H A R D</p>	<p>Left and Right Housing Cover Case Set for Switch Joy-con Clear Transparent Purple</p>
<p>DIEHARD - NsParts-129</p>	 <p style="text-align: center;">D I E H A R D</p>	<p>Complete Screws and Key Button Springs Set for switch Joycon Right+Left</p>
<p>DIEHARD - NsParts-130</p>	 <p style="text-align: center;">D I E H A R D</p>	<p>Complete Screws and Key Button Springs Set for switch Joycon Right+Left +Opening tool kit</p>
<p>DIEHARD - NsParts-131</p>	 <p style="text-align: center;">D I E H A R D</p>	<p>Screw+springs+tools as photo for NS switch</p>
<p>DIEHARD - NsParts-132</p>	 <p style="text-align: center;">D I E H A R D</p>	<p>Inner Rechargeable Battery CTR-003 1300mAh 3.7V for Switch Pro Controller - Capacity 800mAh</p>
<p>DIEHARD - NsParts-133</p>	 <p style="text-align: center;">D I E H A R D</p>	<p>OEM Controller Rubber Conductive Pad Silicon Buttons For Switch Pro Controller Repair Replacement Contacts</p>

<p>DIEHARD - NsParts-134</p>	 <p style="text-align: center;">D I E H A R D</p>	<p>Motherboard Connector Ribbon Flex Cable 14pin For NS NX Switch Pro Nintendo Switch Pro Controller Mainboard</p>
<p>DIEHARD - NsParts-135</p>	 <p style="text-align: center;">D I E H A R D</p>	<p>Complete Screws and Key Button Springs Set for Switch Joycon Left and Right</p>
<p>DIEHARD - NsParts-136</p>	 <p style="text-align: center;">D I E H A R D</p>	<p>Screwdriver Trigram Cross and Anti-Static Tweezers Tool Set for Nintendo Wii Wii DS 3DS Switch</p>
<p>DIEHARD - NsParts-137</p>	 <p style="text-align: center;">D I E H A R D</p>	<p>Replacement Original R Right Buttons Switch Parts for NS Switch Joycon</p>
<p>DIEHARD - NsParts-138</p>	 <p style="text-align: center;">D I E H A R D</p>	<p>Original Joycon SL SR Screws Replacement for NS Switch - 2Pcs</p>
<p>DIEHARD - NsParts-139</p>	 <p style="text-align: center;">D I E H A R D</p>	<p>Original Joycon Motherboard Screws Replacement for NS Switch Console - 2Pcs</p>

DIEHARD - NsParts-140	 <p style="text-align: center;">D I E H A R D</p>	Original L R Slider Stripped Screws Replacement for Nintendo Switch Console
DIEHARD - NsParts-141	 <p style="text-align: center;">D I E H A R D</p>	Original Rear Kickstand Fixing Plastic Back Bracket Buckle Lock Key for NS Switch
DIEHARD - NsParts-142	 <p style="text-align: center;">D I E H A R D</p>	Replacement Complete Housing Shell Case for Nintendo Switch Console - Clear Red
DIEHARD - NsParts-143	 <p style="text-align: center;">D I E H A R D</p>	Replacement Complete Housing Shell Case for Nintendo switch Console - Clear Blue
DIEHARD - NsParts-144	 <p style="text-align: center;">D I E H A R D</p>	Replacement Housing Shell Case Top+Bottom with Stand for Nintendo switch Console - Clear Red
DIEHARD - NsParts-145	 <p style="text-align: center;">D I E H A R D</p>	Replacement Housing Shell Case Top+Bottom with Stand for Nintendo switch Console - Clear Blue

<p>DIEHARD - NsParts-146</p>	 <p style="text-align: center;">D I E H A R D</p>	<p>Replacement Complete Housing Shell Case for Nintendo switch Console - Clear White</p>
<p>DIEHARD - NsParts-147</p>	 <p style="text-align: center;">D I E H A R D</p>	<p>Replacement Complete Accessoires and Screws for NS Switch Cosnole</p>
<p>DIEHARD - NsParts-148</p>	 <p style="text-align: center;">D I E H A R D</p>	<p>Original Housing Shell Case for Nintendo Switch Gampad 6.2inch</p>
<p>DIEHARD - NsParts-149</p>	 <p style="text-align: center;">D I E H A R D</p>	<p>Replacement Analog Stick Silicon Grip Cap for Switch and Lite 8Colors (1PC)</p>
<p>DIEHARD - NsParts-150</p>	 <p style="text-align: center;">D I E H A R D</p>	<p>Superhero Supercap Thumb Grips Analog Caps Silicone Rubber For Switch and Lite Miki Yellow</p>
<p>DIEHARD - NsParts-151</p>	 <p style="text-align: center;">D I E H A R D</p>	<p>RCM X86 Dongle Auto RCM Payload Support SX/ OS ReiNX RajNX for NS Switch</p>

DIEHARD - NsParts-152	 <p style="text-align: center;">D I E H A R D</p>	V5 RCM Loader Auto Clip Jig Tool Dongle Kit For Nintendo Switch NS
DIEHARD - NsParts-153	 <p style="text-align: center;">D I E H A R D</p>	RCM Clip New Improved For SWITCH RCM Tool Clip Short Circuit RCM Loader One Payload Bin Injector Transmitter for Switch
شماره	عكس	مشخصات قطعه
قطعات کنسول نینتندو سویچ NS Console		
 <p style="text-align: right;">POWERED BY TAJAN -CO 2021-2022</p>		